

5. CARE AND MAINTENANCE

Always remove batteries from the remote control console when they have drained out completely or are not in use for a longer period of time. Keep it away from direct sunlight, high humidity, high temperature or excess heat. Ensure that the tires are clean for optimized grip. Gently wipe the tires with a damp cloth whenever they become dirty. Do not immerse the toy or any part of it in water to clean it. This can damage its electronic components. Before using the toy car, please ensure that it is not damaged and safe to use.

6. SAFETY PRECAUTIONS

The toy should be used by children aged 4 years or above. While using it for the first time, this toy car should be safely set up under adult supervision. Do not try to modify any part of the toy, which may negate your authority to use it. Rechargeable batteries of this toy car should be charged under adult supervision only. While charging the toy, do not touch the electric outlet and the charging port with bare/wet hands to avoid electric shock. Adults should examine the USB cable, plug, enclosure or other parts of the toy regularly. Strictly adhere to this instruction manual while operating the toy.

7. DISPOSAL INFORMATION

Never dispose of the toy along with the household waste. If / When you decide to dispose of this toy car, discard it in e-waste container that are in accordance with the local environmental laws, guidelines and battery recycling procedures.

Manufactured by / Packed by / Marketed by & Customer Care Executive Address:

MIRANA INNOVATIONS PRIVATE LIMITED

719, Warehouse-5, Titanium Logistics Park, Rajoda, Bavla, Ahmedabad,
GJ, India - 382 220.



www.miranatoys.com



MEGA RANGER

ALL TERRAIN 4WD

APP & REMOTE CONTROL SMART CAR



AR GAME
COMPATIBLE



VARIABLE SPEED
REMOTE CONTROL



TURBO
BOOST SPEED



C-TYPE
USB CHARGING



SMOKE
EXHAUST



BRIGHT LED
HEAD LIGHTS



SMOOTH
SUSPENSION



4 WHEEL
DRIVE



SPEED
CONTROL



6 LIGHTING
MODES



DURABLE
SHOCKS



6 OVERSIZED
TIRES



DURABLE
MATERIAL



POWERFUL
DUAL MOTOR



FULL
FUNCTION



FOR AGES
4 & ABOVE

WELCOME

Enjoy the flexibility of controlling your Smart Toy using both the dedicated Mirana Mobile App and the included remote control. Choose the method that suits your play style and switch seamlessly between them.


Please read this document and the safety instructions carefully before using the all-new smart toy car.

www.miranatoys.com

1. BUILT-IN BATTERY

The toy comes with a rechargeable 2000 mAh battery. Don't attempt to modify, remove or replace the battery as it may damage it and cause overheating and injury. Don't cut, tear, puncture, compress or deform the toy by disassembling it. Follow the below instructions for charging its battery:


1. Turn the toy upside down to check the charging port.
2. Plug the USB charging cable provided in the box into the (5V-2A) DC input charging slot at the bottom of the toy.
3. Red LED will glow up while charging.
4. Green LED will glow up when the toy is fully charged.
5. Remove the adapter when the Green LED glows up.
6. The toy will not charge if it is on. To charge switch off the toy first.



2000 mAh Rechargeable Li-Ion Battery (Included)


2. APP PLAYING INSTRUCTIONS

1. Download the "Mirana" App from the Google Play Store or the App Store for Android and iOS devices, respectively.
2. Turn on the power switch of the toy given its bottom.
3. Switch on the Bluetooth® of your mobile phone and open the Mirana App installed on your phone.
4. Click on the "Add Toy" button in the Mirana App.
5. Click on the toy in the App to pair it and set a name.
6. Your toy and the Mirana App are now connected. Click on any game to start.
7. For directional control, use the left round button on the console screen to move the vehicle forward and backward. Use the right round button to turn left or right.
8. For an extra burst of speed, you can use the (energy symbol) button to activate the Boost function.
9. To exit the game press on the pause button in top right corner.



3. REMOTE PLAYING INSTRUCTIONS


1. Turn on the remote and turn on the car. The lights will stop blinking when the remote is connected.
2. For directional control, use the left joystick on the controller to move the vehicle forward and backward. Use the right joystick to turn left or right.
3. For an extra burst of speed, you can use the "UP" button to activate the Boost function.
4. The "Down" button can be used to turn on / off the Smoke Light & Headlight.



5. To activate the Smoke, Press the "Center" button.
6. While the car is in motion, you can use the "Right" button to drift the car to the right, and the "Left" button to drift the car to the left.

4. SMOKE EXHAUST WATER TANK

Prior to starting the smoke exhaust, it is essential to verify if there is water in the tank. If the water is used entirely, it should be promptly refilled with the dropper provided in the box. Operating the smoke exhaust without water can potentially reduce its lifespan or cause irreversible damage.



Water Tank Capacity - 30ml